Cord Set Up

If you have one (1) 2-line phone cord:

One cord should have your 2 lines.

If you have two (2) 1-line phone cords:

You will need to get a splitter. Take this diagram to your local electronics store and they will help you choose the correct one.

OR

A single line phone cord for line 1 can go into the line 1+2 port. Another single line phone cord for line 2 can go into the line 2 port.

No Dial Tone?

If your phone has a single line cord with 3 or more lines on it, this system will not work. You will need to contact either your local service provider or the manufacturer of your previous non-RCA telephones.

Bluetooth® Setup & Use

Setup



1. Press MENU (soft key).
2. Scroll down to **BLUETOOTH®** SETTINGS and press SELECT.
3. Select ADD NEW DEVICE and press SELECT.

Note: Refer to the instruction manual for your cell phone device on the proper procedure to add and pair a new device. It is important that your phone have the **Bluetooth®** feature enabled and be in "discoverable" mode while attempting to pair it for the first time with the RCA 25216.

4. The base will display "Add New Device - Searching".
5. The phone will display a list of all **Bluetooth®** devices within range. Select your **Bluetooth®** cell phone and press ADD.
6. Your cell phone will ask you for a PIN or password. Use the number keys on your cell phone keypad to enter the default PIN, which is 0000. When the devices are paired successfully, the display on your 25216 should read <Name or model number of your cell phone> CONNECTED.

Use

To place calls over **Bluetooth®**, simply treat the Cell button as if it were an additional landline button. You may place cell calls on hold, use speed dial buttons and even conference cell calls together with landline calls.

Note: Due to limitations inherent to cell phones, long pauses while dialing may cause the number to be dialed prior to completing the dialing sequence. Please dial the complete number without pauses.

quick start guide

25216

RCA ViSYS™

www.rca4business.com

For Customer Assistance call 1-800-511-3180

RCA is a trademark of RCA Trademark Management S.A., used under license.

Button Layout

Easy to Navigate Menu's

1. To navigate around the menus use the volume up and down buttons and the soft keys just below the screen.



Note: To choose a soft key option, press the button directly under that part of the screen.

Note: The Prev and Next buttons on the left and right are also used in menus to switch between some options.

Storing Phone Numbers

1. To make a one touch dial press STORE.
2. Press the one touch button to be programmed.
3. Use the keypad to enter the name for this contact. This is done the same way names can be entered into cell phones.
4. Press SAVE to enter the phone number and press SAVE to store.